


WaterMaster™ Accessories

369 DrainEdge™



369 DrainEdge™

369 DrainEdge™	Method	Results
Fire Testing	NFPA 285	Pass

369 DrainEdge™

DESCRIPTION

- Perforated, embossed polyolefin material that allows drainage at the head of system penetrations.
- Speeds and simplifies application of the Parex USA EIFS with Drainage.
- Eliminates need for pre-wrapping or rasping the back of boards at terminations.
- Eliminates the need for mineral wool and track at terminations.

USES

- Termination of system at heads of penetrations.
- Termination at wall base in lieu of track, especially for curved walls.

COMPOSITION

- Spunbonded polyolefin
- Color: White

PACKAGING

- Individual 200 ft. roll in a carton
– Width 7 in. (2.8cm)

SHELF LIFE

- Reference Parex USA Expiration Date of Products Technical Bulletin.

STORAGE

- Store enclosed out of sunlight.
- Protect from dirt and moisture.

LIMITATION

- Metal head flashing must be used behind DrainEdge™.

PAREXUSA

INSTALLATION

- Before Installing 369 DrainEdge™:
 - Flashing at heads of openings must be in place prior to application of Parex USA water resistive barrier coatings and 396 Sheathing Tape.
 - Parex USA water resistive barrier coatings with 396 Sheathing Tape embedded at metal head flashing must be in place and dry.
- 369 DrainEdge™ Installation:
 - Cut off and discard the unperforated material at the beginning of the roll, approximately 6-7 in. (15.2-17.8cm).
 - Place 369 DrainEdge™ over the head flashing so that 2 in. (5.1cm) of the lower edge of the 369 DrainEdge™ will be exposed after the EPS insulation is installed over it. 5 in. (12.7cm) of 369 DrainEdge™ will be behind the EPS once the EPS is installed.
DO NOT STRETCH 369 DrainEdge™ DURING INSTALLATION.
 - Secure any 369 DrainEdge™ with corrosion resistant staples or with small dabs of any Parex USA adhesive spaced approximately 16 in. (40.6cm) apart.
- Backwrap Mesh Installation:
 - DO NOT EMBED BACKWRAP MESH IN BASECOAT OVER 369 DrainEdge™.
 - Apply 355 Standard Mesh over 369 DrainEdge™ and secure its top edge with corrosion resistant staples or with small dabs of any Parex USA adhesive spaced approximately 16 in. (40.6cm) apart.
 - Cut backwrap mesh wide enough to wrap 6 in. (15.2cm) in back of the EPS and a minimum of 5 in. (12.7cm) onto the outer face of the EPS.
 - Install EPS, basecoat, and finish coat.
 - Trim off the 2 in. (5.1cm) of exposed 369 DrainEdge™ with a sharp knife after finish coat is dry.

WARNING

- Read complete warning information printed on product container prior to use. For medical emergency information, call 1-800-424-9300.
- For more information on handling this product refer to its Safety Data Sheet (SDS). The most current SDS and Product Data Sheet (PDS) can be found on our website.
- This Product Data Sheet has been prepared in good faith on the basis of information available at the time of publication. It is intended to provide users with information about the guidelines for the proper use and application of the covered product(s) under normal environmental and working conditions. Because each project is different, Parex USA, Inc. cannot be responsible for the consequences of variations in such conditions, or for unforeseen conditions.

PAREXUSA

Parex USA, Inc., a California Corporation
4125 E. La Palma Ave., Suite 250
Anaheim, CA 92807
www.parexusa.com
866-516-0061 Tech Support: 800-226-2424